

If you have not already purchased items of our brand we recommend you to rely to the conversion table below in order to choose your correct size. For any doubt please email us to the following address: info@capobianco.org

		46 (IT) - 42 (EU)	48 (IT) - 44 (EU)	50 (IT) - 46 (EU)	52 (IT) - 48 (EU)	54 (IT) - 50 (EU)	56 (IT) - 52 (EU)	58 (IT) - 54 (EU)	60 (IT) - 56 (EU)	Tolerance CM+/CM -
1	Half waist width	37	39	41	43	45	47	49	51	1
2	Half pelvis width	49,5	51,5	53,5	55,5	57,5	59,5	61,5	63,5	1
3	Leg Lenght, inseam	78,5	80	81,5	83	84	84	84	84	1
4	Leg opening width	18,5	19	19,5	20	20,5	21	21,5	22	0,5



How to Measure:-

1. Waist Width: Lay the pants flat (front side up) on a horizontal surface. Measure the distance at the narrowest point of the waistband from one end to the other.

2. Hip Width, below the pocket: Lay the pants flat (front side up) on a horizontal surface. Measure the distance, keeping the tape measure below the pockets, from one side to the other.

3. Leg Length, inseam: Lay the pants flat (front side up) on a horizontal surface. Measure the distance from the crotch down to the bottom end of the pants.

4. Leg Opening Width: Lay the pants flat (front side up) on a horizontal surface. Measure the distance at the narrowest point of the leg opening from one end to the other